


Selection Guide


PROXIMITY SENSOR

Ordering information(Cylindrical type)



- 1) IEC standard item are available only for PRCMT and PRWT type.
- 2) Normal Open, Normal close output are only for DC 2-wire and AC 2-wire type.
- 3) Short Type is only for DC 3-wire and PR12 Type.

Ordering information(Rectangular type)



- 1) Differential frequency type is only for PS17 type.
- 2) Upside sensing type is only for PS12, PS17 Type.
- 3) Normal Open, Normal Close output are only for DC 2-wire and AC 2-wire type.
- 4) N3, P3 output is only for AS80 Type.
- 5) DC 2-wire type is only for PS17 Type.